

# C6/C6 Z06 RF Installation

- Please check out this instruction first to know how to mix soapy solution and applying vinyl:  
[http://www.vettestripes.com/Vette%20Instruction/How\\_To\\_Peel\\_Off\\_Stripes.pdf](http://www.vettestripes.com/Vette%20Instruction/How_To_Peel_Off_Stripes.pdf)
- Install the big stripes first following the 2 pictures below for correct stripes placements. You will need to install the piece right next to the headlight first. The other piece is about 1.5" away from the first piece (it is actually 1.537" or 1 17/32").
- Install the border pieces after all main pieces got laid down perfectly.
- Wait couple hrs and peel off the masking tape at 180 degrees angle.



# C6/C6 Z06 RF Installation

C6 Z06

