

C6 Fender Stripes Installation

- You fender stripes kit will come in 2 pieces. One narrower (front stripes) and one wider (rear stripe).
- Mix about 7 – 10 drops of baby shampoo (or window tinting film aid which can be bought at any auto parts store) with 1 quart of water in spray bottle :
(http://www.vettestripes.com/Vette%20Instruction/How_To_Peel_Off_Stripes.pdf)
- Clean up the area where you about to install the stripes on the fender. Also clean inside and underneath the fender where the stripes will bend around.
- Do not let the backing paper got wet or it will permanently stick to the vinyl.
- The front stripe will be 10” to 11” away from the corner of the front fender and the hood. The cut line with the arrow will be parallel with fender line and 1/8” overlap the fender so you can bend it down after installation
- Spray the soapy solution on the area you about to install the stripes
- Wet your hand and peel 1 piece of stripes off the backing paper. Spray some soapy solution on the adhesive side of the vinyl and put it on the fender.
- The rear stripe is about ½” – 1” from the front stripe and the cut line is also parallel with the fender line.
- If you don’t have a squeeze, you can use a towel to wrap around your credit card as a squeeze.
- Wait about 30 minutes to let the vinyl dried out a bit and start massaging the stripes to bend inside and underneath the fender.

C5 Fender Stripes Placements

- You got 3 pieces fender stripes where 2 pieces are the same width and the 3rd one is wider.
- For 2 smaller pieces, there is one piece longer which got the same length as the wider piece.
- Those longer pieces will be the second piece.
- You will need to install this longer piece first which is 11.25" away from the lamp opening along the fender line.
- The => arrow is showing what side of the stripes facing toward the engine bay. The cutting line of the fender stripes is parallel and stick out 3/16" so you will bend it around the fender after the stripes drying out. Make sure to clean that area and the area underneath the fender wells real clean since the stripes will bend around those areas.
- Install the shorter piece to your liking position next to the longer piece. Many people put 1/2" apart.