

C7 Front Grill Blackout

- . The front grill blackout is either 3M 1080 metallic black (carbon flash) or 3M 1080 black carbon fiber. They are both wrap material so you can do dry application which mean you can peel up and reapply during installation.
- . Just peel off the backing paper as you go. Don't peel off all backing paper since it will stick up together.
- . Only leave up to $\frac{3}{32}$ " (a bit less than $\frac{1}{8}$ ") to wrap over the top of the chrome bar since it does not have much room if you try to tuck in more than $\frac{3}{32}$ ". Using credit card to tuck the vinyl in.
- . When you get about $\frac{1}{3}$ to go, with most the backing paper still on that $\frac{1}{3}$ remaining, you can try to lay it down all the way to the end to see if you need to stretch it a bit more or if it is already longer than it suppose to be (because you may have stretch it a bit earlier)
- . If it is longer, just using scissor to trim it off when you get to the end. If it is a bit short, start stretch it a bit.
- . Clean it up with goo-gone (Lowes or Home Depot) or 3M adhesive remover after finish installation.

