

C7 Stingray C7.R Side Stripe Installation

- To be able to install your C7 Stingray C7.R side stripes, you will need to remove your side vents.
- Remove the wheel well plastic splash guard off the front fender.
- Unscrew all 3 torx screws holding the wheel well liner. By opening up the liner, you can reach in with 8mm socket or wrench, remove 3 nuts that holds the fender vent in place.
- Then you can remove the vent off the fender



C7 Stingray C7.R side stripe

- After the vents got removed, clean up wax and inside really well since the side stripes will bend inside the vents
- Install the stripes around the vent and have it hang over the vent $\frac{1}{4}$ " since you will bend that $\frac{1}{4}$ " inside the vent. Also, it will be around $\frac{1}{4}$ " longer than the fender line right next to the door so you can bend it inside as well
- Using hair drier to heat up and start bending the stripe inside the vent and fender line at the door.
- Install the stripe on the door lining up with the one on the fender. This piece is also about $\frac{1}{4}$ " longer on each side so you can bend them inside the door.
- Install the stripe on the rocket panel lining up with the door. Also leave it up about $\frac{1}{4}$ " to bend it inside the door.

