

Chevrolet Corvette C7 Z51 Stingray Front Fender Vent

Installation

Components List:

2 x Carbon fiber front fender vent Left and
Right side

Approximate Installation Time:

1/2 Hour




Installation Procedures:



1. Remove the wheel well plastic splash guard off the front fender.



2. Unscrew all 3 torx screws holding the wheel well liner. By opening up the liner, you can reach in with 8mm socket or wrench, remove 3 nuts that holds the fender vent in place.

	<p>3. Once you have the vent removed off the fender, locate all 3 studs on the vent, and transfer them over the carbon fiber one.</p>
	<p>4. Tips: By putting a masking tape to hold the stud in place will help these studs not to slide out of the vent while you try to install it back to the fender.</p>
	<p>5. Place the new carbon vent to the fender and secure it with 3x8mm nuts, and reinstall the wheel well line screw and splash guard back. Repeat step to other fender.</p>
	<p>Installation is complete!</p>