

C7 Grand Sport & Z06 rear brake scoop enhancement instruction

- These decals will be in wrap materials. Even though they can be applied wet but for this rear brake scoop enhancement, they will need to apply dry!
- Just peel off a little from the bottom of your decal and start install from the bottom of your rear brake scoop first and slowly peel off more and align it with your rear brake scoop.



- Do not press down the vinyl just yet since you may need to pull it out and realign.
- Do not stretch the vinyl too much since then you may need to trim it!
- After everything aligner well with your rear brake scoop, you can start massage it down using your clean finger or wrap your finger with micro towel if your skin is too rough :D which may scratch vinyl.
- Using hair drier to head them up since wrap materials are head activated vinyl