

C7 Side Stripes Instruction

- These stripes will come with paper premask to hold them together!
- Please read premask instruction to know how to install stripes with premask.

1. Ordering these stripes in 1 color:

- All 3 stripes will be masked together. Identify driver and passenger stripes.
- If you have a second person to help out which will make the installation much easier since these stripes are long.
- Align the front stripe parallel to the front fender side vent and slide them inside about 1/8"-1/4" and about 2" above the bottom of the side vent. Have the second person lay the other half stripes down to the back of the car.
- The most important point to align the stripes to line up well with the rear quarter panel. If you don't like the stripes to go on rear bumper, you can slide more inside the side vent or angle the rear to the upper rear quarter panel by lower the front to about 1" from the bottom of the front fender side vent.
- After peeling off paper premask, using a sharp razor to cut between all panels including rear bumper and rear quarter panel. Bend the extra inside each panels. The same thing applies to gas door cap as well!

2. Ordering these stripes in 2 colors:

- The bottom 2 stripes will be masked together and the top stripes with a removable spacer will be masked together.
- Follow all the above steps to install the bottom 2 stripes first!
- After peeling off paper premask of the bottom 2 stripes, installing the top stripes with spacer right next to the bottom 2 stripes without any gap. The spacer will be removed after installation to have the correct gap between the top and bottom 2 stripes.
- Remove the paper premask for the top stripes.
- Remove the spacers between the top and bottom 2 stripes.