

# C7 Stingray Side Vent Extension and Side Spear Stripe One Piece Installation

- We suggest to remove the side vents to have much easier installation. Here are instruction to remove the side vents.

- Remove the wheel well plastic splash guard off the front fender.



- Unscrew all 3 torx screws holding the wheel well liner. By opening up the liner, you can reach in with 8mm socket or wrench, remove 3 nuts that holds the fender vent in place.



- Then you can remove the vent off the fender



- After the vents got removed, clean up wax and inside really well since the side stripes will bend inside the vents.
- Install the stripes around the vent and have them overlap over the vent lines where the side vents sitting, about 1/8".
- If you don't want to remove the side vents, I would suggest that you must do wet installation for much easier alignment.
- Install the stripes around the side vent and try to pull the vent out a bit to slide your stripe under the side vent. After the stripe slides under the side vent, start to align it to line up with the top body lines of the vent.
- Squeeze it down and may need to use a hair drier to smooth out at some areas.
- Be careful since there is so much dirt under the side vents; therefore, during slide the stripes under the vents, they may kick out some dirt and may create bubble sports.